

Алматы (7273)495-231
 Ангаск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922) 49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
 Иваново (4932)77-34-06
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-61
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Ноябрьск (3496)41-32-12
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37

Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Саранск (8342)22-96-24
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сыктывкар (8212)25-95-17
 Сургут (3462)77-98-35
 Тамбов (4752)50-40-87

Тверь (4822)63-31-35
 Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Улан-Удэ (3012)59-97-51
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70


Казахстан (772)734-952-31

<https://kompass.nt-rt.ru> || kaf@nt-rt.ru

Монтажные плиты гидравлических клапанов D-4 серии DSGM-02, DSGM-03, DSGM-04, DSGM-06, DSGM-10

Base plate for solenoid valves

DSGM



DSGM-02-02-B4 DSGM-02-02-S4
 DSGM-03-03-B4 DSGM-03-03-S4


How to order

DSGM	-02	-02	-B4	-PT
Model No	Valve size	Port size	Port direction	Connected thread type
Base plates for solenoid valves	02 03	02: 1/4 " 03: 3/8 "	B4: 4 Ports in bottom S4: 4 Ports in side	PT: Standard BSP: Special NPT: Special SAE: Special

Remarks: standard type are B4, S4 & PT for special, please tell us.

02(6 valve size) Base plates for solenoid valves

DSGM-02




MODEL	PORT	P	T	B	A	WEIGHT
DSGM-02-02-B4*		B	B	B	B	1.1
DSGM-02-02-S3B1*		S	B	S	S	
DSGM-02-02-S4*		S	S	S	S	
DSGM-02-02-S2B2*		B	B	S	S	

Mounting Surface: ISO 4401 standard

PORT SIZE: PT 3/8 " or PT 1/4 "
 PORT POSITION: S=SIDE B=BOTTOM
 ※ SUITABLE THREAD PT, BSP & NPT

03(10 valve size) Base plates for solenoid valves

DSGM-03



MODEL	PORT	P	T	B	A	WEIGHT Kg	
						E=30	E=40
DSGM-03-03-B4*		B	B	B	B	2.2	
DSGM-03-04-B4*		B	B	B	B	2.2	
DSGM-03-04-S3B1*		S	B	S	S		3.1
DSGM-03-04-S4*		S	S	S	S		3.1

Mounting Surface: ISO 4401 standard

PORT SIZE: PT 3/8 " or PT 1/2 "
 PORT POSITION: S=SIDE B=BOTTOM
 ※ SUITABLE THREAD PT, BSP & NPT

DSGM-04



DSGM-04-04-B4







DSGM-04-04-S4

■ How to order:

DSGM	-04	-04	-B4	-PT
MODEL NO	VALVE SIZE	PORT SIZE	PORT DIRECTION	CONNECTED THREAD TYPE
BASE PLATES FOR SOLENOID PILOT OPERATED DIRECTIONAL CONTROL VALVES	04 16 VALVE SIZE	02:1/4 " 06:3/4 "	B4:4 PORTS IN BOTTOM S4:4 PORTS IN SIDE	PT: BSP: STANDARD SPECIAL NPT: SAE: SPECIAL SPECIAL

© Remark: Standard types are B4,S4&PT for special types, please contact us.

Mounting Surface : ISO 4401 standard

**DSGM-06**

DSGM-06-06-B4





DSGM-06-06-S4

■ **How to order:**

DSGM	-06	-06	-B4	-B4
MODEL NO	VALVE SIZE	PORT SIZE	PORT DIRECTION	CONNECTED THREAD TYPE
BASE PLATES FOR SOLENOID PILOT OPERATED DIRECTIONAL CONTROL VALVES	06	06:3/4 "	B4:4 PORTS IN BOTTOM	PT: STANDARD BSP: SPECIAL
	25 VALVE SIZE		S4:4 PORTS IN SIDE	NPT: SPECIAL SAE: SPECIAL


© Remark: Standard types are B4,S4&PT for special types, please contact us.

Mounting Surface : ISO 4401 standard



BASE PLATES FOR SOLENOID PILOT OPERATED DIRECTIONAL CONTROL VALVES


DSGM-10



DSGM-10-10-B4

10(32 valve size)Base plates
for solenoid pilot operated
directional control valves

DSGM-10




© General screw BSP&NPT

How to order:

DSGM	-10	-10	-B4	-PT
MODEL NO	VALVE SIZE	PORT SIZE	PORT DIRECTION	CONNECTED THREAD TYPE
BASE PLATES FOR SOLENOID PILOT OPERATED DIRECTIONAL CONTROL VALVES	10 32 VALVE SIZE	10:1 1/4 "	B4:4 PORTS IN BOTTOM	PT: BSP: STANDARDSPECIAL NPT: SAE: SPECIAL SPECIAL

Mounting Surface : ISO 4401 standard



Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93