

Алматы (7273)495-23
 Ангарск (3955)60-70-56
 Архангельск (882)63-90-72
 Астрахань (852)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (462)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-3
 Владикавказ (8672)28-90-48
 Владимир (4922) 49-43-8
 Волгоград (844)278-03-48
 Вологда (872)26-4-59
 Воронеж (473)204-5-73
 Екатеринбург (343)384-55-89

Ижевск (342)26-03-58
 Иваново (4932)77-34-06
 Иркутск (395)279-98-46
 Казань (843)206-0-48
 Калининград (402)72-03-8
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-4-49
 Кострома (4942)77-07-48
 Краснодар (86)203-40-90
 Красноярск (39)204-63-6
 Курск (472)77-3-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-8

Киргизия (996)32-96-26-47

Магнитогорск (359)55-03-3
 Москва (495)268-04-70
 Мурманск (852)59-64-93
 Набережные Челны (8552)20-53-4
 Нижний Новгород (83)429-08-2
 Новокузнецк (3843)20-46-8
 Ноябрьск (3496)4-32-2
 Новосибирск (383)227-86-73
 Ноябрьск (3496)4-32-2
 Омск (382)2-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (842)22-3-6
 Петрозаводск (842)55-98-37
 Псков (82)59-0-37

Россия (495)268-04-70

Пермь (342)205-8-47
 Ростов-на-Дону (863)308-8-5
 Рязань (492)46-6-64
 Самара (846)206-03-6
 Саранск (8342)22-96-24
 Санкт-Петербург (82)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-3-93
 Симферополь (3652)67-3-56
 Смоленск (482)29-4-54
 Сочи (862)225-72-3
 Ставрополь (8652)20-65-3
 Сыктывкар (822)25-95-7
 Сургут (3462)77-98-35
 Тамбов (4752)50-40-97

Казахстан (772)734-952-3

Тверь (4822)63-3-35
 Тольятти (8482)63-9-07
 Томск (3822)98-4-53
 Тула (4872)33-79-87
 Тюмень (3452)66-2-8
 Улан-Удэ (302)59-97-5
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-2
 Хабаровск (422)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (35)202-03-6
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (42)23-90-97
 Ярославль (4852)69-52-93

<https://kompass.nt-rt.ru> || kaf@nt-rt.ru

Гидравлические цилиндры



Key Features

OMA	-CA	-B	-Ø100	R045	S2000	-140K	-Y
SERIES NUMBER	TYPE OF MOUNTING	CUSHIONING DEVICE	CYLINDER BORE (mm)	ROD DIA (mm)	STROKE (mm)	WORKING PRESSURE	ROD ADAPTER
None: Standard Type OMA: Shaft Teeth Screw On & Shaft Key Insert Type OMB: Shaft Teeth Screw	FA TYPE FB TYPE LA TYPE LB TYPE CA TYPE CB TYPE TC TYPE	B: 2 sides R: rod side H: rear cover side None: non-cushioned		R045: Piston Type R45R: RAM Type		70k: 70 kgf/c m ² 140k: 140 kgf/c m ² 210k: 210 kgf/c m ²	1:1 1 Type Y: Y Y Type O: O O Bearing Type None: Without

On & Shaft Key Insert Type OMC: Shaft Teeth Screw On & Shaft Key Insert Type OMD: Production Machinery Purposes OME: Synchrono us Hydraulic Cylinder RAM: RAM Type Hydraulic Cylinder	TA TYPE						
--	---------	--	--	--	--	--	--

SERIES NUMBER

OMA Series: CA- I Type Shaft Teeth Screw On(Round Type) (Large Model)		CA- II Type Shaft Key Insert	
OMB Series: FA- I Type Shaft Teeth Screw On(Round Type) (Large Model)		FA- II Type Shaft Key Insert	
OMC Series: CA- I Type (Shaft Teeth Screw On) (Round Type) (Small Type)		OMC CA- II Type	
OMD Series: (Round Type)(Small Type) CA- I Type		OMD CA- II Type Shaft Teeth	

(Production Machinery)		Scree w	
OME Series: Synchronou s Hyd. Cylinder (parking Equipment) CA Type		RAM Type CA Type	

Алматы (7273)495-23
Ангарск (3955)60-70-56
Архангельск (882)63-90-72
Астрахань (852)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (462)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-3
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-8
Волгоград (844)278-03-48
Вологда (872)26-4-59
Воронеж (473)204-5-73
Екатеринбург (343)384-55-89

Ижевск (342)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-0-48
Калининград (402)72-03-8
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-4-49
Кострома (4942)77-07-48
Краснодар (86)203-40-90
Красноярск (39)204-63-6
Курск (472)77-3-04
Курган (3522)50-90-47
Липецк (4742)52-20-8

Киргизия (996)32-96-26-47

Магнитогорск (359)55-03-3
Москва (495)268-04-70
Мурманск (852)59-64-93
Набережные Челны (8552)20-53-4
Нижний Новгород (83)429-08-2
Новокузнецк (3843)20-46-8
Ноябрьск (3496)4-32-2
Новосибирск (383)227-86-73
Ноябрьск (3496)4-32-2
Омск (382)2-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (842)22-3-6
Петрозаводск (842)55-98-37
Псков (82)59-0-37

Россия (495)268-04-70

Пермь (342)205-8-47
Ростов-на-Дону (863)308-8-5
Рязань (492)46-6-64
Самара (846)206-03-6
Саранск (8342)22-96-24
Санкт-Петербург (82)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-3-93
Симферополь (3652)67-3-56
Смоленск (482)29-4-54
Сочи (862)225-72-3
Ставрополь (8652)20-65-3
Сыктывкар (822)25-95-7
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-3

Тверь (4822)63-3-35
Тольяти (8482)63-9-07
Томск (3822)98-4-53
Тула (4872)33-79-87
Тюмень (3452)66-2-8
Улан-Удэ (302)59-97-5
Ульяновск (8422)24-23-59
Уфа (347)229-48-2
Хабаровск (422)92-98-04
Чебоксары (8352)28-53-07
Челябинск (35)202-03-6
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (42)23-90-97
Ярославль (4852)69-52-93